



# FEATHER BANNERS

## SET UP



1 Assemble the long rod sections making sure they fit flushly together.



2 Insert the rod into the long sleeve. Push the rod all the way to the end of the sleeve.



3 Insert the elbow/short rod into the short sleeve and fit it into the end of the long rod.



4 Hook the cord over the base.  
If the banner is too tight or too loose adjust the cord and cleat.



5 To insert the banner into the base ensure the ring on the Quick Connect is **up**. Insert the rod and push the ring **down** to lock it in place.



## CARING FOR YOUR BANNER

- Ensure the elbow and the long rod are flush fitting for extra durability.
- Ensure the banner has even tension by adjusting the cord and cleat at the base.
- Erect the banner in an area big enough for 360° rotation so it doesn't rub against walls, plants, street signs etc.
- Use the correct hardware for the correct surface, for example a Stake for snow or sand, a Universal base on tiles or carpets.
- When using a ground stake ensure the ground is clear of any obstacles such as pipes and rocks.
- Take care when hitting the stake into the ground ensure you do not hit the spindle.



- Before putting up the banner ensure it will be clear of overhead electrical cables when standing at its full height.
- Clean with warm, soapy water.
- Dry thoroughly before packing away.
- To increase the life-span of your banner take down at night or in winds exceeding 25 knots. Remember, colour lasts longer in the shade.